

## **Loading/Unloading in the Delivery Yard**

### **Truck drivers must:**

- keep locking devices clearly marked
- ensure that all locking devices are correctly unlocked and
- keep locking devices in such condition that prevents their twisting during loading/unloading
- ensure that their vehicles are parked straight in the loading square.

### **When loading/unloading may be safely commenced, truck drivers must:**

- go to the kiosk and hold down the **green** lamp button
- remain in/beside the kiosk until loading/unloading is complete.

### **If a different lock position is required during loading**

- release the **green** lamp button once the straddle carrier has left the truck
- then walk around the truck and change the container lock positions
- go to/in the kiosk and hold down the **green** lamp button until the straddle carrier has left the loading square.

### **If something should go wrong**

- switch on the **orange** lamp to notify the straddle carrier driver
- wait until the straddle carrier has reversed away from the truck before correcting the fault.

**Once the **green** lamp is lit, remain in/at the kiosk.**

**Never go to another loading square to provide assistance.**

**Contravention of these regulations may result in expulsion from the container terminal and permit withdrawal.**